

beanbag care guide

**BEAN
BAGS
R-US®**

premium 1680D range

made with premium
polyester fabric
suitable for indoor
and outdoor use.

Thanks for choosing Bean Bags R Us. Your bean bag is manufactured to the highest quality, with double stitching and over locked seams. The heavyweight Polyester Fabric will last for years and is backed by our 12 month warranty. This fabric is stain and water resistant. For best results, we recommend spot-cleaning where possible.

Keep this in a handy place for future reference!

filling your beanbag

Fill with Standard Polystyrene Beans available in 100 litre bags from most department stores. You can vary the volume of beans to suit your preference.

For optimum comfort we recommend:

Bermuda Triangle Premium.....	400L
Big Bob Chair Premium.....	500L
Big Boppa Premium.....	350L
Billy The Kid Premium.....	200L
Cayman Premium.....	600L
Freaky Cousin Premium.....	200L
Hayman Premium.....	400L
Media Lounge Premium.....	300L
Merlin Premium.....	350L
Round Ottoman Premium.....	200L

Handy Tip: Your product comes with a separate inner liner bag, which can be removed even when full of beans, if you need to clean or change the cover. To fill your bag put the beans into the inner liner first, then open the long zip on the cover and insert the full inner liner.

care instructions

This product comes with an inner liner bag, so when it's time to clean your Bean Bag, all you need to do is remove the inner liner full of beans to wash the cover and simply reverse the procedure by putting the inner liner bag full of beans back into the cover! The fabric is treated and is water repellent and resists stains so generally only spot cleaning will be needed. Should you choose to wash see instructions below.



Hand or gentle machine wash.

Keep separate on gentle cycle in cold water only.



Air dry. **Do not** soak, tumble dry, bleach, iron or dry clean.



To spot clean wipe with a damp cloth and mild detergent. Do not use products containing bleach.

To avoid mould and mildew, clean and dry your bean bag before storing. Store in a dry place indoors, and avoid prolonged exposure to the elements.

safety locking zip

Bean Bags R Us products are fitted with quality YKK childproof locking safety zippers as required by law. These guard against children accessing the bean bag filling.

Please close all zippers and do not allow children to be present when filling. Please use a paper clip to open the zipper by inserting the paper clip under the zip lock and lifting. Once the lock is disengaged slide the zip to open or close.



FOR THE SAFETY OF CHILDREN ENSURE THE PAPER CLIP IS REMOVED ONCE THE ZIP IS CLOSED.



WARNING:

CHILDREN CAN SUFFOCATE IF BEAN BAG FILLING IS SWALLOWED OR INHALED. DO NOT LET CHILDREN CLIMB INSIDE THIS BEAN BAG. A BEAN BAG IS NOT A SAFE SLEEPING SURFACE FOR AN INFANT UNDER 12 MONTHS OF AGE. KEEP AWAY FROM NAKED FLAME.